

FIAT 500 ABARTH INDUCTION KIT FITTING INSTRUCTIONS

Tools needed:

- Socket set
- Trim tool
- Drill
- 70mm Hole saw

Kit Includes:

- Alloy induction pipe 'inc bracket, M6 x 16, M6 x 10 bolt & 2 x washers'
- Alloy intake scoop 'bolts, washers and nuts supplied'
- Pro hose silicon hose 'includes 2 x 40mm jubilee clips'
- AIRTEC Motorsport foam filter 'includes 1 x 80mm Jubilee clip'



AIRTEC ✖
MOTORSPORT

AIRTEC ✖
MOTORSPORT

Instructions:



1. Open the bonnet and secure, then loosen x2 jubilee clips and remove. If you have 'use once' clip then remove by twisting screwdriver as will be replaced by jubilee clips inside of kit.

2. Now remove 10mm bolt securing filter down and lift off stock filter by pulling up releasing rubber mounts holding filter down from underneath.



3. Once the filter has been removed, you can start removing the scuttle panel. Start by removing x2 plastic covers as shown in picture below underneath the caps 13mm nuts securing wipers. You remove these scuttle panel.



these you will find covering the which will be windscreen will need to to remove the

4. Now remove located of the scuttle



x3 plastic clips across the top panel.

5. You can now panel off the washer scuttle panel



lift the scuttle and disconnect jets from the to remove.

6. Once scuttle panel has been removed you can locate where the scoop will be fixed for your intake. Fix in place by using hardware supplied 2 x M5 x 12 button head bolts, 4 x washers and 2 x Nyloc nuts (no drilling is required).
7. Now you will need to cut a hole in the lower scuttle for the airflow from the scoop to reach the induction kit. We suggest using a 70mm hole saw for this to provide maximum airflow.



8. You can now pipework and clip, once connect the hose to the



fit the Airtec tighten jubilee secured supplied silicon induction kit.



9. Now secure the intake pipe into the engine bay by using supplied bracket and fixings. Start by installing the M6 x 16 bolt and washer to secure the bracket into the engine bay then use M6 x 10 bolt and washer to attach the bracket to the pipework as shown below.



10. You can now install your Airtec motorsport air filter to complete your induction kit. Simply slide your new filter on and tighten jubilee clip using 7mm socket or flat bladed screw driver.

11. Now reinstall your upper scuttle and re-attach windscreen wipers in reverse order of installation. Check everything has been tightened correctly and enjoy!

