

## AIRTEC Fiesta ST180 Eco Boost Intercooler fitting guide



1. Undo 2 x T30 Torque bolts and 4 cross hex plastic screws



2. Undo 2 x T30 torx bolts on each headlight and remove headlight giving enough room to unclip the multi plug which is located at the bottom



3. Undo 4 x T30 Torx bolts along inner wheel arch liner each side



4. Remove 2 push fittings along bottom of bumper



5. Undo the 3 x 10mm bolts securing wing to the bumper (3x bolts each side)



6. Unplug fog lights from front bumper and carefully remove bumper.
7. Remove front intercooler under tray by removing 5 x 8mm bolts (2 on top & 3 along bottom)



8. Remove the 2 x 8mm bolts holding intercooler, loosen jubilee clips on boost pipes and then the intercooler can be removed.



9. Remove lower support bracket, this is no longer required and can be kept if car goes back to standard or thrown away.



10. Swap over rubber grommet that are located on top of standard intercooler



11. Install new intercooler in reverse of removal. Enjoy your new AIRTEC intercooler upgrade

