

## AIRTEC Front mount intercooler for Fiesta MK6 TDCI

**PLEASE NOTE:** This intercooler kit will require trimming to the bumper and radiator cradle.



### Tools required:

- T27 & T25 Torx Sockets
- 8mm & 10mm socket
- Selection of extension bars
- Ratchet
- Flat blade screw driver
- Grinder
- Safety goggles

### Fitting kit:

- 2X M6 X 20 socket head
- 2X M6 nylock
- 2X M6 pan washers
- 2X M6 Mudguard washers

1. Remove grill by unclipping top locating clips



2. Remove headlights 3x T27 torx



3. Remove 2x T25 torx securing inner arch to bumper



4. Remove 3 x 10mm bolts securing bumper to wing



5. Unclip sides of bumper and remove. Making sure to unclip fog lights



6. Remove standard cooler by undoing 2x8mm bolts then lifting up + out of bottom locators



7. Line up AIRTEC intercooler fixing bracket holes with pre-drilled holes on crash bar and loosely bolt into place with supplied bolts



8. Cut radiator cradle front fixings to allow clearance for new boost pipes and fit as pictured.



9. Test fit bumper fitment. Lower section of grill needs trimming, we have pictured a rough location of trimming, more trimming may be required.



**THANK YOU FOR JOINING  
THE COOLING REVOLUTION...**