

## Transit Custom M Sport AIRTEC intercooler fitting instructions.



### Tools Required:

T27 Torx socket

10MM Socket

Trim removal tool

Jubilee driver

Ratchet and selection of extensions

**1. Remove intercooler air guide by undoing 4x T27 torx & 2x 10mm bolts**



**2. Undo jubilee clips securing boost pipe to intercooler and remove**



**3. Secure radiator and undo 4x 10mm bolts securing radiator and intercooler cradle and remove cradle**



**4. Undo 4x T27 torx securing intercooler**



**5. Bolt new intercooler into place using original fixing bolts**



**6. Secure radiator cradle back into place**

**7. Trim foam padding on intercooler air guide with a sharp Stanley blade**



**8. Re-fit intercooler air guide and enjoy your AIRTEC intercooler!**

