

Land rover discovery 2 AIRTEC intercooler fitting guide.

1. Remove standard intercooler

2. Place new airtec intercooler in to radiator mounting location and bolt to radiator with supplied m8 dome head bolts.



Please note: Pictures are from prototype kit fitted.

3. Secure intercooler to body using supplied polyurethane bushes and tighten using supplied M8 nut and bolts.

