

## Airtec intercooler fitting instructions for the AUDI A4/A5 2.0 TFSI.



### Tools needed:

T25, T27 Torx socket

10mm socket

Extensions & ratchets

Philips screw driver

5mm allen key

10mm spanner

### Fitting kit:

4x M6 X 16 socket head bolts

2x M6 Small mudguard washers

2x M6 nylock nuts

4x M6 pan washers

1. Undo 4x T27 torx securing top bumper slam panel



2. Undo 2x T25 securing top of bumper



3. Undo 2x T25 torx securing inner arch to bumper



4. Remove engine undertray



5. Undo 2x 10mm bolts securing bumper to inner wing, then unclip side of bumper



6. Remove bumper making sure to unclip fog lights. Store in a safe place to prevent damage



7. Remove standard cooler by removing boost pipes. Undo 1x T25 on passenger side and unclip cooler.



8. Trim plastic air feed guides as marked



9. Fit new airtec intercooler into place. The bottom sits into original mounting points and secure top of cooler to crash bar with supplied bracket.



10. Fit supplied silicon boost pipes (For petrol models only)



11. Re install bumper following instructions in reverse