

## AIRTEC Motorsport Fiesta spoiler risers fitting guide.



Fits: Fiesta MK7 – ST180, Zetec S, 1.0 Ecoboost.

1. **Unbolt standard spoiler 4x T20 torx, 2x 8mm bolts**



2. **Before removing spoiler, remove brake light 2x T20 torx and unclip brake light loom and washer pipe**



3. **Remove spoiler by carefully pulling backwards to unclip from car**



4. **With spoiler removed its now time to fit your spoiler raisers as pictured below**



**5. Cover original holes with black stickers provided as pictured**



**6. Fit spoiler with supplied M6 bolts. Make sure spoiler risers are lined up correctly, once happy with fitment tighten all bolts**

