

## AIRTEC Fiesta ST180 oil cooler fitting guide



### Tools required:

T27 torx socket

8mm, 10mm, 13mm sockets

4mm, 6mm, 12mm, Allen key

Selection of extensions & ratchet

Jubilee / screw driver

Drill

6mm drill bit

Oil filter wrench

26mm spanner

1. With bumper removed, fit oil cooler mounting plate, if you already have our AIRTEC stage 3 intercooler this bolts in place of the original top mounting bracket. If you have stage 1 AIRTEC cooler, use stabilising bracket as pictured.



2. Bolt oil cooler to bracket with supplied nuts and bolts



3. Run oil lines from cooler below crash bar into engine bay



4. Fix oil cooler lines securing bracket to M8 stud on gearbox



5. Remove standard oil modine and join coolant lines with supplied connector



6. Fit sandwich plate to engine with supplied adaptor bolt and fit new oil filter



7. Fit oil lines to sandwich plate, start car up and check for any leaks.
8. Re-check oil level and re fit bumper