

TDCI induction kit fitting guide.

Place new AIRTEC air box top onto OEM air box lid, mark holes around outer edge @ the same time mark a rough guide where AIRTEC logo is positioned. Remove AIRTEC top and then drill the securing holes using a 7mm drill, the bigger hole (AIRTEC Logo) this can be drilled out with a 90mm hole saw or using your 7mm drill bit to drill multiple holes close together so you can remove the centre to allow air flow through the new AIRTEC top.

