

AIRTEC Mitsubishi Colt CZT fitting guide

1. Remove front bumper and standard OEM intercooler



2. Check hose layout before installing



3. Remove front crash bar, install pipework and intercooler into position, re install crash bar to check clearances all okay, tighten and secure intercooler with fixings supplied.



4. Some minor trimming may be required on the back of the bumper



**THANK YOU FOR JOINING
THE COOLING REVOLUTION...**