

Airtec intercooler fitting guide for Renault Traffic



Remove standard intercooler by removing 2 x 10mm securing bolts above each boost pipe. Remove both boost pipes and lift intercooler from bottom securing pegs.



Fit your new Airtec intercooler by locating it in to the original lower pin locations. Then bolt the top of the intercooler in to place using the supplied m6x16 socket head and washer and Re fit boost pipes.



**THANK YOU FOR JOINING
THE COOLING REVOLUTION...**