

Golf MK5/6 PD140 Diesel.



Tools required:

Access to a vehicle lift or floor jack and axle stands.

Drill.

3mm drill bit.

7mm hose clamp driver.

T25 Torx socket.

Ratchet and extensions.

Cross head screw driver.

Dremel or similar tool for trimming bumper.

Safety eyewear, footwear, gloves and protective clothing are also recommended.

1. Undo 4x T25 Torx securing grille & remove.



2. Undo 4x T25 Torx holding inner arch to bumper.



3. Undo 1x T25 Torx holding bumper to arch.



4. Undo 8x T25 Torx securing bottom of bumper.



5. Undo 2x T25 Torx securing top of bumper



6. Remove bumper making sure to unplug fog lights & headlight washer pipe.



7. Remove engine under tray.



8. Remove standard intercooler hoses, these will not be re fitted.



9. Place intercooler in position, mark and drill securing holes with a 3mm drill bit.



10. Bolt intercooler in place with screws supplied.



11. Remove temp sensor from original bracket and clip onto cooler.



12. Relocate horns with supplied brackets.



O/S



N/S

13. Fit silicone boost hoses with clips provided.



14. Trim lower grill area of bumper before refitting.



**THANK YOU FOR JOINING
THE COOLING REVOLUTION...**