Ford Fiesta Mk8 Air Feed Guide (with Stage 3) Fitting Instructions

Tools needed:

- Ratchet
- 5mm Allen Key
- 7mm Socket / Hose Driver

Kit Includes:

- AIRTEC Motorsport air feed scoop
- Air feed Hose
- 2x 80mm jubilee clips
- 1x M6x20mm Hex Head Bolt
- 1x M6 washer





Instructions:

1. Remove the bolt from the right-hand side bracket using a 5mm Allen key. Then install the supplied M6x20mm bolt and washer through the air feed scoop and into the existing bracket and intercooler.







2. You can now attach the air feed hose onto the air feed scoop using the supplied jubilee clip. The air feed can now either go to your AIRTEC Motorsport oil cooler or intake.



