

# Hyundai i20N De-Res Pipe Fitting Instructions

## Tools needed:

- Needle Nose Pliers
- Flat-Bladed Screwdriver
- 8mm Socket

## Kit Includes:

- 1x AIRTEC Motorsport connector
- Pro Hoses Silicone Hose
- 2x 70mm Jubilee Clips

PLEASE THOROUGHLY READ THESE INSTRUCTIONS AND MAKE SURE YOU ARE FAMILIAR WITH THE STEPS BEFORE CARRYING THEM OUT



# Instructions

1. Raise the vehicle using either a ramp or axle stands and ensure it is secure.
2. Working under the car, at the back of the engine you will be able to see the original pipe coming off of the turbo. Pull the clip down on the edges to release it and then you will be able to pull the connector off of the turbo.



3. On the other end of the hose you will need to remove the cap. To do so, undo the hose clamp using an 8mm socket and remove the hose along with the connector.



4. Remove the O-ring from the original connector and fit it into your new AIRTEC Motorsport connector. Then reinstall onto the vehicle reusing the clip.



5. Finally, install the new silicone hose onto the car with jubilee clips and once happy with the fitment fully tighten.

