

AIRTEC Motorsport Astra MK5 VXR engine breather fitting instructions.



Fitting kit:

- 4 Jubilee clips
- 2 M6 mudguard washers
- 1 M6 X 16 socket head
- 1x M6 nylock
- 1x breather tank
- 2x silicone joiners

Tools required:

- 5mm Allen key
- 10mm spanner
- Jubilee driver

1. Bolt breather tank to original airbox fixing. Please note, hole may need to be drilled to 6mm.



2. Fit silicone hoses as pictured

