

Toyota Yaris GR Rear Differential Cooling Guide Fitting Instructions

Tools needed:

- Ratchet
- 5mm Alan Key
- 10mm Socket or Spanner

Kit Includes:

- AIRTEC Rear Differential Cooling Guide

Fixings:

- X1 M6 x 20mm Socket Head Bolt
- X1 M6 x 80mm Socket Head Bolt
- X3 M6 x 20mm Mudguard Washer
- X1 M6 Nyloc Nut

PLEASE THOROUGHLY READ THESE INSTRUCTIONS AND MAKE SURE YOU ARE FAMILIAR WITH THE STEPS BEFORE CARRYING THEM OUT



Instructions:

1. Start by locating the mounting points for the cooling guide, one will be a threaded tab and the other a slot in the rear subframe as shown below.



2. Now you can install the cooling guide by securing the front of the guide in place using the provided M6x20mm Socket head bolt with a washer, do not tighten fully as you will need some movement to align the rear of the guide.



3. Lastly install the M6x80mm Socket head bolt with washer through the slot of the rear subframe then through the cooling guide and add an additional washer with M6 nyloc nut to secure the guide in place. Once happy with fitment tighten all fixings securely.

