

Fiesta Mk6 ST150 Airtec Alloy radiator, Fan surround & Air-con radiator fitting Instructions.



1. Once you have removed your old radiator, remove the fan surround and hook it onto your new Airtec radiator, mark the surround to where you need to drill (use picture below as guide), you will now need to drill 2 x 7mm holes, when drilling surround, rest it on a piece of wood.



2. Once you have drilled the holes into the surround, hook it back onto the radiator and secure with bolts provided.



3. Do not remove Air-con, pictures are for instruction only, Hook the lower part of the Air-con radiator onto the Alloy brackets, as shown below.



4. Now fit the top securing brackets, start with the left hand side bracket, it has a custom made rubber grommet that slides over the Air-con re-gassing pipe, this secures the Air-con radiator into position



5. The radiator can now be fitted, reverse order of removal.

