

Airtec Focus RS Alloy Radiator Fan Surround and Air-Con Radiator Mounting.



1. Drill x2 8mm holes in your original fan surround as shown below



2. Now take the x2 M6 stainless bolts and attach your fan surround onto to your Airtec Radiator



3. Fitting your Air-con radiator onto your Alloy radiator use's the x3 rubber grommets, these attach to 3 of the corners of the Air-con rad then carefully slide the rad across so that all 3 grommets are on your new rad



4. Then cable tie the 4th corner to secure, as shown below 'Do not remove Air-con radiator from car.

