

VAG MQB Dogbone Mount Billet Insert Fitting Instructions

Tools needed:

- 21mm socket
- Lever bar
- Torque wrench

Kit Includes:

- VAG MQB Dogbone Mount Billet Insert

PLEASE THOROUGHLY READ THESE INSTRUCTIONS AND MAKE SURE YOU ARE FAMILIAR WITH THE STEPS BEFORE CARRYING THEM OUT



Instructions

1. Raise the vehicle into the air using either a jack and axle stands or a vehicle lift using the manufactures recommended jacking points.
2. Locate the bolt holding the dog bone mount to the chassis and undo using a 21mm socket.



3. Insert your AIRTEC Motorsport billet insert and then reinstall the bolt. You may need to lever the engine towards the back of the car slightly to realign the bolt with the hole. Use a torque wrench to tighten the bolt to **130nm/96lb ft.**

