

Peugeot 308 GTi Engine Cover Fitting Instructions

Tools needed:

- Socket Set

Kit Includes:

- 1x AIRTEC Motorsport Engine Cover
- Fitting Kit - 2x M6x25 Button Head bolts, 2x M6 Pan Washers, 3x Spacers

PLEASE THOROUGHLY READ THESE INSTRUCTIONS AND MAKE SURE YOU ARE FAMILIAR WITH THE STEPS BEFORE CARRYING THEM OUT



AIRTEC 
MOTORSPORT

Instructions:

1. Open the bonnet and locate the two bolts holding the original engine cover in place.



2. Now fit the new plate in place using the supplied bolts, washers and spacers. Use two spacers on the left-hand side and one on the right-hand side.

