

Hyundai i20N De-Res Pipe Fitting Instructions

Tools Required:

- Needle Nose pliers
- Flat-Blade Screwdriver
- 8mm socket and ratchet

Kit Contents:

- 1x Pro Hoses Silicone Hose
- 1x AIRTEC Motorsport Connector
- 2x Jubilee Clips



PLEASE THOROUGHLY READ THESE INSTRUCTIONS AND MAKE SURE YOU ARE FAMILIAR
WITH THE STEPS BEFORE CARRYING THEM OUT

Instructions:

1. Working underneath the car, at the back of the engine you will be able to see the original pipe coming from the turbo (highlighted with orange arrow). Pull the spring clip down on the edges to release it and then you will be able to pull the connector off of the turbo.



2. On the other end of the hose release the jubilee clip and then remove the connector.



3. With the original hose out, remove the O-Ring from the connector and fit it into your new AIRTEC Motorsport connector. Then install onto the vehicle reusing the original spring clip.



4. Once installed, you can now fit the silicone hose in place using the supplied jubilee clips to secure it.