

# Ford Fiesta ST180 Mk7 Bumper Canard Fitting Guide

## Tools Required:

- Drill
- 6.2mm Drill Bit
- 4mm Allen Key
- 10mm Spanner

## Kit Contents:

- 2x AIRTEC Motorsport Canards
- 10x M6x16mm Button Head Bolts
- 10x Nyloc Nuts
- 20x M6 Washers



PLEASE THOROUGHLY READ THESE INSTRUCTIONS AND MAKE SURE YOU ARE FAMILIAR WITH THE STEPS BEFORE CARRYING THEM OUT

# Instructions:

1. There's a good amount of leeway when fitting this, so once you're happy with the location and fit against the bumper, measure 55mm from above the foglight trim to mark the bottom of the canard location.



2. Measure 115mm from below the headlight to mark the top of the canard location.





3. Mark out the five fitting holes underneath and then use a 6.2mm drill bit to make the holes. Remove the fixings securing the front part of the arch liners in place and then you will have access to the inside of the bumper to nut and bolt the canards in place.

