

# BMW F8x M3/M4 GTS-Style Under Belly Pan Fitting Instructions

## Tools Required:

- Ratchet and 8mm Socket

## Kit Contents:

- 1x AIRTEC Motorsport Aluminium GTS-Style Under Belly Pan



PLEASE THOROUGHLY READ THESE INSTRUCTIONS AND MAKE SURE YOU ARE FAMILIAR  
WITH THE STEPS BEFORE CARRYING THEM OUT

# Instructions:

1. Remove the 12 bolts (blue arrows) to release the original under belly pan. Then place the AIRTEC Motorsport replacement as shown below, and secure reusing the original bolts.

**Please note:** Make sure the pan is slotted above the oil cooler cover (orange arrow).

