

<b>Vehicle:</b>	Ford Fiesta Mk7 & ST150
<b>Product:</b>	Torque Mount
<b>Part number:</b>	ATMSFO20



## Fitting Notes

When installing the mount, make sure the fitment of the rear bushing that attaches to the car is snug with no sideways movement.

If there is, use the washers supplied in the kit as shims to take up any slack if there's a side gap.

Some cars seem to require them, some don't, so we supply the washers/shims with every kit.