

Vehicle:	Honda Civic FK2 Type R
Product:	Front Brake Cooling Air guides
Part number:	ATMSHON27



Kit Contents:

1x AIRTEC Motorsport Air Guide Front Section Left-Hand Side	4x M6x25mm Hex Head Bolts
1x AIRTEC Motorsport Air Guide Rear Section Left-Hand Side	4x M6 Nyloc Nuts
1x AIRTEC Motorsport Air Guide Front Section Right-Hand Side	4x Mudguard Washers
1x AIRTEC Motorsport Air Guide Rear Section Right-Hand Side	

Tools Required:

Ratchet and Socket Set	Trim Removal Tool
Breaker Bar/Wheel Brace	

PLEASE THOROUGHLY READ THESE INSTRUCTIONS AND MAKE SURE YOU ARE FAMILIAR WITH THE STEPS BEFORE CARRYING THEM OUT

Instructions:

1. Start by lifting the car in the air safely and remove both front wheels.



2. Locate the original brake cooling air guides and undo the two bolts securing them in place. You can then remove them from the car.



- Next, take the rear section of the AIRTEC Motorsport brake cooling air guide and insert the two M6x25mm Hex bolts supplied in the kit as shown.



- Secure the new air guide in the same location as the original using the two Nyloc nuts and washers supplied in the kit.



5. Under the car remove the original air guide from the under tray by undoing the two 10mm bolts (blue arrows) and one push-fit clip (orange arrow).



6. Finally, install the front section of the AIRTEC Motorsport brake cooling air guide by locating the top bracket into the under tray (blue arrow) and then sliding it back and pushing it up to align the holes (orange arrows). You can then secure reusing the two 10mm bolts removed in Step 5 (green arrows).



7. Finally, repeat the process for the other side and then refit the wheels.

